

Your spa may be equipped with a tee-handled jet wrench. Should one of the smaller, 2 inch [5cm] diameter, jets become loose, this wrench can be used to retighten it. To tighten the jets, insert the hex end of the wrench into the hex shaped hole in the center of the jet and turn clockwise as shown. Do not over tighten. Hand tight is sufficient.

